



# PETROVAC-VACUUM PUMP SYSTEM

## LEGEND

1. PetroVac Positive Displacement Vacuum Pump & Motor
2. UL Cabinet
3. Red Jacket Pump Control Box (Supplied by Contractor/Not Shown)
4. Veeder-Root TLS-450Plus Console With SCLD Module (Supplied by Contractor/Not Shown)
5. Vacuum Tubing and Fittings
6. Air Discharge Filter
7. Air Discharge Pipe With Mushroom Insect Screen
8. Explosion-Proof Wiring Components (As Required by Code)
9. Explosion-Proof Switch (With Lockout)
10. Explosion-Proof "Pump On" Indicating Light
11. Multiport Vacuum Block
12. Vacuum Gauge
13. Rigid Conduit (Supplied by Contractor)
14. EYS (Supplied by Contractor)
15. Vacuum Check Valve (Not Shown)



When The Veeder Root Calls For Vacuum, The Following Occurs:

1. Veeder Root Communicates to Turbine Relay
2. Turbine Relay Closes Sending Power To Pump
3. Pump Turns On Initiating Vacuum
4. Vacuum Module Receives Vacuum

# PETROVAC

**PETRO SPECIALTIES, INC**  
 27570 Commerce Center Dr. #228  
 Temecula CA 92590  
 Phone: (888) 606-8265  
 Petrospecialties.com



## Part #'s

PV331-USV7F-WHT  
 PV332-USV15-WHT  
 PV333-USV7F-GRY  
 PV334-USV15-GRY

PV335-USV7F-SS  
 PV336-USV15-SS